








Cover with toggle switch for time switch and blind switch or button



| Specification | Order No. | Packing unit | PS | EAN |
|---|-----------|--------------|----|---------------|
|  cream white glossy | 0666 01 | 5 | 01 | 4010337666011 |
|  pure white glossy | 0666 03 | 5 | 01 | 4010337666035 |
|  pure white matt | 0666 27 | 5 | 01 | 4010337666271 |
|  anthracite | 0666 28 | 5 | 11 | 4010337666288 |
|  colour aluminium | 0666 26 | 5 | 11 | 4010337666264 |
|  black matt | 0666 005 | 5 | 11 | 4010337036586 |
|  grey matt | 0666 015 | 5 | 11 | 4010337081401 |

Notes

- This cover plate can be used universally by replacing the accompanying symbol plates for blind and time.

Scope of supply

- Symbol plates for blind (,) and time (15 to 120 min or 30 to 60 min) are included in the scope of supply.
